

3. The ColecoVision Programmers Manual - Detail Sections

TABLE OF CONTENTS

	Page
III. GRAPHICS GENERATION SOFTWARE.....	3-1
3.1. Chip Driver Level.....	3-1
3.1.1 READ_VRAM.....	3-4
3.1.2 WRITE_VRAM.....	3-6
3.1.3 READ_REGISTER.....	3-8
3.1.4 WRITE_REGISTER.....	3-11
3.1.5 FILL_VRAM.....	3-13
3.1.6 MODE_1.....	3-15
3.2 Table Level.....	3-17
3.2.1 Table Managers.....	3-21
3.2.1.1 INIT_TABLE.....	3-22
3.2.1.2 GET_VRAM.....	3-25
3.2.1.3 PUT_VRAM.....	3-29
3.2.2 Table-Oriented Graphics Routines.....	3-32
3.2.2.1 REFLECT_VERTICAL.....	3-35
3.2.2.2 REFLECT_HORIZONTAL.....	3-40
3.2.2.3 ROTATE_90.....	3-45
3.2.2.4 ENLARGE.....	3-51

TABLE OF CONTENTS

	Page
3.2.3 Sprite Reordering Software.....	3-57
3.2.3.1 INIT_SPR_ORDER.....	3-61
3.2.3.2 WR_SPR_NM_TBL.....	3-63
3-3 Object Level.....	3-65
3.3.1 Object Types.....	3-65
3.3.1.1 Semi-Mobile.....	3-66
3.3.1.2 Mobile.....	3-66
3.3.2.3 Sprite.....	3-66
3.3.1.4 Complex.....	3-67
3.3.2 Object Data Structure.....	3-67
3.3.2.1 Graphics Data Area.....	3-67
3.3.2.2 Status Area.....	3-68
3.3.2.3 OLD_SCREEN.....	3-68
3.3.3 ACTIVATE.....	3-69
3.3.4 PUTOBJ.....	3-71
IV. INTERRUPT HANDLING AND WRITE DEFERRAL.....	4-1
4.1 INIT_WRITER.....	4-3
4.2 WRITER.....	4-5

TABLE OF CONTENTS

	Page
V. TIMING SOFTWARE.....	5-1
5.1 Non-Repeating Timer.....	5-2
5.2 Repeating Timer.....	5-2
5.3 TIMER_TABLE.....	5-2
5.3.1 Mode_Byte.....	5-3
5.3.2 Value_Word.....	5-3
5.3.3 TIMER_DATA_BLOCK.....	5-4
5.4 INIT_TIMER.....	5-5
5.5 TIME-MGR.....	5-7
5.6 REQUEST_SIGNAL.....	5-9
5.7 TEST_SIGNAL.....	5-12
5.8 FREE_SIGNAL.....	5-14
VI. CONTROLLER SOFTWARE.....	6-1
6.1 Controller Data Area.....	6-2
6.2 POLLER.....	6-6
6.3 DECODER.....	6-8
6.4 CONT_SCAN.....	6-10
6.5 UPDATE_SPINNER.....	6-11

TABLE OF CONTENTS

	Page
VII. SOUND GENERATION SOFTWARE.....	7-1
7.1 LST_OF_SND_ADDRS and PTR_TO_LST_OF_SND_ADDRS...	7-2
7.2 SOUND_INIT.....	7-2
7.3 PLAY_IT.....	7-4
7.4 SOUND_MAN.....	7-6
7.5 PLAY_SONGS.....	7-8
7.6 Application.....	7-9
VIII. BOOT_UP SOFTWARE.....	8-1
8.1 Power-Up Procedure.....	8-1
8.2 Title Screen.....	8-3
8.3 Cartridge Present Identifier.....	8-3
IX. MISCELLANEOUS UTILITIES.....	9-1
9.1 ADD816.....	9-1
9.2 DECLSN.....	9-3
9.3 DECMSN.....	9-4
9.4 MSNTOLSN.....	9-5
9.5 RAND_GEN.....	9-6
9.6 LOAD_ASCII.....	9-7

TABLE OF CONTENTS

	Page
X. DEFINED REFERENCE LOCATIONS.....	10-1
10.1 OS ROM.....	10-1
10.1.1 Europe/America Byte.....	10-3
10.1.2 Restart Vectors.....	10-5
10.2.3 Graphics Tables.....	10-6
10.2 CART_ROM.....	10-6
10.3 CRAM Areas.....	10-8

APPENDICES

A. Bibliography
B. Graphics Documentation
C. Sound Documentation
D. ColecoVision Bulletins
E. Jump Table
F. OS_SYMBOLS
G. Timing Software Data Structure
H. OS Subroutine Library
I. ASCII Generator Set