

1 repeating timers will also be modified to reflect this
2 move.

3
4 NOTE: In this special case, TIME_MGR, or any other
5 routine that accesses or modifies the
6 TIMER_TABLE, should NOT be called during the exe-
7 cution of FREE_SIGNAL. (This may occur if
8 TIME_MGR was called on interrupt). ColecoVision
9 Bulletin No. 0010 (Appendix D) suggests the
10 solution of using DEF_INT to defer interrupts.

11
12
13 Parameters:

14
15 SIGNAL_NUM Previously defined output from
16 REQUEST_SIGNAL.

17
18 Side Effects:

19
20 - Destroys AF, BC, DE and HL.
21
22
23
24
25
26

SECTION VI
CONTROLLER INTERFACE

Most applications involving the hand controller require similar needs in decoding and debouncing those inputs. The operating system addresses those needs in one general purpose routine, POLLER. POLLER will decode and debounce either all or selected portions of the hand controller hardware and place the processed data in the Controller Data Area selected by the pointer in CONTROLLER_MAP.

Special applications may require non-standard decoding of the inputs available from the hardware; therefore, entry points to lower level routines are available.

There are four routines available to access controller inputs:


- POLLER
- DECODER
- CONT_SCAN
- UPDATE_SPINNER

6.1 Controller Data Area

The pointer in CONTROLLER_MAP points to the user-defined
CRAM area which is accessed and/or modified when POLLER
is called. Users define this address by placing the
location of the 12 bytes of the CRAM Controller Data
Area at cartridge location CONTROLLER_MAP. They are
defined as follows:

+0	Player 1 enable	
+1	Player 2 enable	
+2	Fire button (left button)	Player 1
+3	Joystick	Player 1
+4	Spinner count (for interface modules)	Player 1
+5	Arm button (right button)	Player 1
+6	Keyboard	Player 1
+7	Fire button	Player 2
+8	Joystick	Player 2
+9	Spinner count	Player 2
+10	Arm button	Player 2
+11	Keyboard	Player 2

Player Enable (+0, +1):



Where bit = 1: Function enabled.

bit = 0: Function disabled.

X = Don't care

While functions are as follows:

Bit 7 = Controller Enable

Bit 4 = Keypad

Bit 3 = Arm Button

Bit 1 = Joystick

Bit 0 = Fire Button

Status of individual portions of the controller map area
when enabled is described as follows:

Fire button:

Status = 040H, if fire button pressed

Status = 0H, if fire button not pressed

Joystick:

<u>Status</u>	<u>Direction</u>
01H	N
03H	NE
02H	E
06H	SE
04H	S
0CH	SW
08H	W
09H	NW

Spinner Switch:

SPIN_SW_CNT is added to the value for position offset.
(Ref to Sec. 6.5)

Arm Button:

Status = 0040H if arm button pressed

Status = 0000H if arm button not pressed

Keypad:

	<u>Value</u>	<u>Key</u>
1		
2		
3		
4	00H	0
5	01H	1
6	02H	2
7	03H	3
8	04H	4
9	05H	5
10	06H	6
11	07H	7
12	08H	8
13	09H	9
14	0AH	*
15	0BH	#
16		
17		
18		
19		
20		
21		
22		
23		
24		
25		
26		

6.2 POLLER

Calling Sequence:

CALL POLLER

Description:

Reads, decodes and debounces all active portions of both controllers. The results are placed in the Controller Data Area.

POLLER's debounce algorithm waits until it finds the data the same for two successive passes before it modifies the Controller Data Area. If a particular portion is disabled, then this routine will still be looking for the second occurrence upon re-enabling. Please note that the POLLER routine cannot interrupt itself.

1

2

Side Effects:

3

-Destroys all except alternate register pairs, does not
destroy alternate AF pair.

4

5

- Zero's SPIN_SW_CNT if that portion of the controller
is enabled. (See UPDATE_SPINNER).

6

7

8

Calls to other OS routines:

9

10

- CONT_SCAN

11

12

13

14

15

16

17

18

19

20

21

22

23

24

25

26

Calling Sequence:

Description:

Parameters:

CNTRLR	SEGMENT NO.	
		The value found in segment number
		will decode these respective
		portions of the controller:

0 = Fire, Joystick, Spinner

1 = Arm, Keypad

OUTPUTS:

IF SEGMENT CHOSEN WAS:

Segment 0

Segment 1

Register H

Fire

Arm

Register L

Joystick

Keyboard

Register E

Spinner

The decoded values are listed in the Controller Data Area.

Side Effects:

- Destroys AF, BC, DE and HL.

Calls to other OS routines:

- CONT_SCAN

6.4 CONT_SCAN

Calling Sequence:

CALL CONT_SCAN

Description:

Reads the actual ports to both controllers and places the data in an OS-defined CRAM area. These locations are labeled as SO_CO, SO_C1, S1_CO and S1_C1.

Side Effects:

- Destroys AF.

6.5 UPDATE_SPINNER

Calling Sequence:

```
ORG 801EH
JP UPDATE_SPINNER
```

Description:

For use with expansion modules only. Interrupt service routine which processes controller spinner switch interrupts (maskable). Decrements OS reserved byte SPIN_SW0_CNT for Controller No. 0 or SPIN_SW1_CNT for Controller No. 1 if spinner is going in one direction; increments byte if spinner is going in the other direction (Ref. Table 10-1).

NOTE: SPIN_SW_CNT is accessed and modified by both DECODER and POLLER if they are called.